
CLOCK INSTRUCTIONS – CITY OF BURNABY RINKS

Mobile Version



Printable Version



NEVCO Model 871 Scoreboard Quick Reference



1. Getting Started

Turn ON the machine (Toggle switch on the right side of unit)

Follow the prompts and click the following:

- 1) DO YOU WANT TO START WHERE TURNED OFF LAST?
- 2) ENTER MODEL NUMBER
- 3) DO YOU WANT TO USE SHOT CLOCK
- 4) DO YOU WANT TO USE PENALTY TIME OUT

3. Entering Scores



ENTER ACTUAL SCORE (this method replaces whatever current score is displaying)



2. Set-up Warm-up or Period Time



USE ATTACHED SWITCH TO START AND STOP CLOCK

4. Entering Penalties



"NOTE: only two penalties per team will display on the scoreboard. HOWEVER, if there are more than two, enter them following the same instructions. As the older penalties expire, the other ones will display.



CLEAR PENALTIES (after recording power play goal)



Model Code 871

